

LEAK AT FAUCET SPOUT / HOW TO REPLACE

If Shower Head loosed causes the leak. Open it and use couple of nail- glue drop onto the thread and secure it back.

