

DRAIN SHOE LEAKS, HOW TO OPEN DRAIN SHOE

- Check Copper Screw, tighten as needed.
- If leak found from vent-hole at bottom of Drain shoe. Remove 4 screws, pull Lever out to swap or replace the O ring .




Fig. 1




Fig. 2